

# **7000CLWB**

Handles multiple applications Grease-free top plate surface 2-inch slide increments

Standard/Moderate duty
On highway only
55,000 lbs vertical load
150,000 lbs drawbar pull
Approx top plate weight 248 lbs

## **Mounting Bracket**

#### **Fontaine LWB Light Weight Air Slide Bracket**

- Innovative weight saving design is lighter than its predecessor without losing an ounce of capacity— Save 20 to 50 lbs depending on configuration
- Computer-aided design features a smaller footprint with steel reinforcement for strength and durability
- New greaseless bracket liner provides consistent lubrication, reduces wear (no metal-to-metal contact) and cuts maintenance costs
- Two-inch slide increments give you greater versatility for improved payload distribution
- Quad-Lock four-point locking system increases locking surface area for greater stability and improved wear characteristics
- Automatically removes slack from the slide assembly for a smoother ride and longer life
- Dual durometer two-piece bushing for improved shock absorption and easier maintenance

### **Top Plate**

#### Fontaine No-Slack® 7000CC Series Cast Steel with Clean Connect™ inserts

- Clean Connect™ inserts reduce friction so that grease is not necessary between the surface of the fifth wheel and the trailer plate
- No-Slack lock self-adjusts to accommodate kingpin wear
  - Switch from trailer to trailer hassle-free
  - Snug, secure connection
  - Reduces shock inputs into frame when braking/accelerating
  - Improves driver comfort
  - Reduces driver complaints
  - Extends service life of components
- Locking trigger helps minimize high-hitching
- Reduces driver frustration
- Reduces tractor, trailer and tire damage
- The industries best defense against false coupling
- Saves expensive wrecker and clean up bills
- Easy coupling force—only 30 lbs!
  - Less wear and tear on the kingpin
  - Extends service life of drivetrain components
- Pull handle is the easiest to operate in the industry
  - Opens easily with a simple, straight pull of the handle
  - No complicated opening sequence to remember

### **Top Plate Performance Options**

- Air actuated—In-cab air release valve located on the dash opens the fifth wheel lock only when the tractor parking brakes are set.
- LST Lock Sensing Technology— Electronic sensors let the driver know that the kingpin is correctly positioned inside the lock and that the fifth wheel is closed. When the sensors indicate a successful coupling, a green light illuminates. After coupling, the system continuously monitors the connection and warns the driver with a red light if a change occurs.



www.fifthwheel.com • 800-874-9780 • Email: parts@fifthwheel.com